



LISTA DE RECAMBIOS / LIST OF SPARES



Nº de parte Item No.	Descripción Description	
		3109 3109D 3109S 3110 3110S
1	Set 2 enchufes 2 Plugs set	ER3109/01
2	Set 2 espejos y 2 faroles 2 rearviews and two lamps set	ER3109/02
3	Set 20 argollas 20 rings set	ER3109/03
4	Set 2 limpiaparabrisas 2 windshieldwipers set	ER3100/04
5	Set 2 bocinas 2 Horns set	ER3109/05
6	Set asideros frontales Front hand holds set	ER3109/06
7	Set asideros puerta cabina Cabin door hand holds set	ER3109/07
8	Set asideros puerta central Central door hand holds set	ER3109/08
9	Rejilla ventilador Fangrill	ER3109/09
10	Rejilla techo Roof grill	ER3109/10
11	Carrocería Bodyshell	ER3109/11
12	Set difusores (superior) Upper diffusers set	ER3100/12
13	Set cristales Glasses set	ER3109/13
14	Set iluminación frontal Front lighting set	ER3100/14
15	Set cabina Cab set	ER3100/15
16	Maquinista Driver	ER34074
17	Set difusores (inferior) Lower diffusers set	ER3100/17
18	Set 4 topes 4 buffers set	ER3100/18
19	Set ganchos y mangueras Hooks and hoses set	ER3109/19
20	Faldón decorativo Decorative snow plough	ER3109/20
21	Faldón funcional Functional snow plough	ER3109/21



LISTA DE RECAMBIOS / LIST OF SPARES

Nº de parte Item No.	Descripción Description	
		3109
		3109D
		3109S
		3110
		3110S
22	Circuito impreso Printed circuit	ER3100/22
23	Set ventilador con motor Fan with engine set	ER3100/23
24	Set contactos movimiento ventilador (x4) Fan contact set (4x)	ER3100/24
25	Set motor principal Main motor set	ER3100/25
26	Caja decoder Decoder box	ER3100/26
27	Set cojinete Bush set	ER24095
28	Set sinfín Worm-gear set	ER24094
29	Cardán Cardan	ER24093
30	Soporte enganche K + muelle K-Coupling holder + spring	ER3100/30
31	Bloque bastidor Frame	ER3100/31
32	Set Enganche Coupling set	ER3100/32
33	Set cobertura bogie Bogie cover set	ER3100/33
34	Set cobertura bogie (con tacómetro) Bogie cover set (with tachometer)	ER3100/34
35	Bulón bogie Bogie pin	ER24097
36	Tapa sinfín Worm-gear cover	ER24096
37	Bogie completo DC DC complete bogie	ER24099A
38	Bogie completo AC AC complete bogie	ER24100A
39	Bogie completo AC para patín AC complete bogie for pick-up shoe	ER24101A
40	Contacto rueda (x4) Wheel current pick-up (4x)	ER3100/40
41	Tornillo + terminal Screw + terminal	ER24111
42	Base bogie + Tornillos DC bogie base + screws	ER3100/42
43	Base bogie para patín AC Bogie base for AC pick-up shoe	ER3100/43
44	Ruedas engranaje y aro DC DC Geared wheels with ring	ER24114
45	Ruedas engranaje y aro AC AC Geared wheels with ring	ER24115
46	Ruedas engranaje sin aro DC DC Geared wheels without ring	ER24116
47	Ruedas engranaje sin aro AC AC Geared wheels without ring	ER24117
48	Ruedas sin engranaje AC AC Wheels without gear	ER24118
49	Set accesorios bogie Accessories set for bogie	ER3100/49
50	Set accesorios para bogie con tacómetro AC Accessories set for bogie with tachometer	ER3100/50
51	Patín AC AC Pick-up shoe	ER6850A
52	Tornillo patín Pick-up shoe screw	ER6851
53	Set de engranajes Gears set	ER3100/53
54	Engranaje doble Double gear	ER24102
55	Caja altavoz Speaker box	ER3100/55
56	Aro de adherencia (x4) Grip ring (4x)	ER3100/56
57	Caja de engranajes Gears box	ER24098A
58	Eje de engranaje Gear axle	ER24107A
59	Depósito fuel Fuel tank	ER3100/59
60	Accesorios depósito fuel Fuel tank accessories	ER3100/60
	Bolsa accesorios Accessories bag	ER3109/61